



1) Start this computer and find the navigation as a disk (in illustration disk - i -)



2) These folders and files will appear in the navigation.

NaviTelAuto_Activation_Key.txt file is important.

You must copy this file to the **Navitel** folders and to **NavitelContent/License** folder.



If there is already such a file in these folders, overwrite it, preferably delete it and then copy it.

3) Then disconnect and turn on navigation (it should start properly) - if it starts properly, you can reconnect navigation to computer and perform update using Navitel Navigator Update Center