


Software recovery guide for Linux navigation devices


1. Charge your personal navigation device (PND).
2. Connect your PND to the PC.



3. Your PND will be recognized as a removable disk. It needs to be formatted: right-click on the disk name and select „Format“.




In the window „Format“, click „Restore defaults“ button and uncheck „Quick Format“. Click „Start“.



4. When formatting is complete, disconnect your PND from the PC. The restore operation of a backup copy of the program (without maps) will begin.



5. Turn on your PND. Navitel Navigator will start with a message about the absence of maps.



6. Connect your PND to the PC. Update the software to the latest version and download maps using the Navitel Navigator Update Center:

www.navitel.cz/downloads/update_center



7. Disconnect your PND from the PC. Navitel Navigator will start automatically - the map will be displayed.

